

Foremost

STEP-BY-STEP
ILLUSTRATED

Instructions

REF: #1008-E

WALLMOUNT FAUCET
Model # FT-7110

INSTALLATION PROCEDURE

5

 STEPS

First turn off your water supply & remove old faucet

1. Seal pipe (1) with teflon tape or compound seal.
2. Screw chrome flanges (2) on the offset nipples (3).
3. Take offset nipples (3) and screw hand tight on pipe coming out of the wall.
4. Tighten as necessary but offset nipples (3) must be 8" apart (center) to avoid leaking.
5. Screw faucet body (5) onto offset nipples. Make sure you use gasket (4) and hand tighten 1/4 turn with wrench.

